

Installation instructions for Spyder RT Floorboards Tread Replacement

When replacing the tread material take the following steps in order to do a professional looking job.

- 1. Remove the Floorboards by removing the 2 locknuts on the bottom of footpegs.**
- 2. Remove the chrome trim and the old tread material and clean all surfaces with lacquer thinner.**
- 3. Place the new tread material in place keeping close to the side edges and press firmly.**
- 4. Place the floorboard tread side down on a cutting board and trim carefully around all edges with a sharp utility knife. Be sure to save the scrap for the Heel/Toe Shifter if you have one.**
- 5. Drill from the bottom through the tread material with a 1/4" drill.**
- 6. Turn the floorboard tread side up and use a countersink in your drill press to trim the bevel for the screw heads.**
- 7. On a flat surface still with the tread side up, install the new 1/4" chrome trim that is included with the kit.**
- 8. Don't forget to install the Heel/Toe Shifter covering if you have one.**

Good luck and contact me with any questions.

Enjoy your new Floorboards and ryde in comfort. C-YA RL

spyderrt@yahoo.com

www.spyderrt.info