

Installation instructions for Spyder RT Floorboards

Remove the 2-10mm bolts from the bottom of the existing footpegs.

There will be a weight that will drop from the bottom of the footpegs.

Remember the position of the weight as you will be replacing it. (These weights are inertial dampeners).

Remove the rubber on the top of the footpeg.

Place the new Floorboards directly on the footpegs and using the new Stainless Steel bolts and stop nuts fasten the Floorboards and the inertial dampeners in place.

You will notice the floorboards have some flex that you didn't notice before. The flexing is normal as the footpegs are rubber mounted to isolate some of the engine vibration and with the added leverage that the floorboard provide the flexing is more noticeable.

Enjoy your new Floorboards and ryde in comfort. C-YA RL

spyderrt@yahoo.com

www.spyderrt.info