

Installation instructions for Spyder F3 Floorboards

- 1. Remove the 2-10mm bolts from the bottom of the existing foot peg.**
- 2. Remove the rubber on the top of the foot peg.**
- 3. Place 1 of the straight cut aluminum spacers on the foot peg, making sure it fits within the foot peg and is aligned with the holes in the foot peg**
- 4. Now place one of the appropriate (left or right) Floorboards with the rubber up, on the Spacer, aligning all the holes.**
- 5. Place 1 of the Stainless Steel machine screws in each hole, lining everything up as you go.**
- 6. Apply 1 of the angled aluminum spacers up from the bottom onto the machine screws, making sure that the angled end is toward the outside of the Spyder**
- 7. Place the flat washer onto the protruding screw from the bottom, and then the locknut provided.**
- 8. Holding the machine screw with a Phillips screwdriver, tighten the lock nuts with a 3/8" wrench until tight.**
- 9. Repeat for the other side.**
- 10. That's it—you're done. Be sure and tell your other F3 buddies. :-)**

Enjoy your new Floorboards and ryde in comfort. C-YA RL

spyderrt@yahoo.com

www.spyderrt.info