

Installation instructions for Spyder RS Floorboards

- 1. Remove the small retaining clip from the bottom of the foot peg retaining pin and drive the pin up and out.**
- 2. Remove the spring and the foot peg from the foot peg bracket.**
- 3. Place the appropriate Floorboard into the foot peg bracket pressing the aluminum rod into the desired rotational position.**
- 4. insure that the rod is firmly against the inner footpeg surface.**
- 5. Mark the rod through the top footpeg hole with a small nail and remove the assembly.**
- 6. Place in a vice so you can drill a 1/4" hole straight through the center of the rod.**
- 7. Take your time and double check your accuracy both X and Y axis.**
- 8. Now place the assembly in position on the Spyder and confirm the proper fit and angle rotation.**
- 9. Drill completely through the aluminum rod with a 5/16" drill bit using the Spyder footpeg holes as a guide.**
- 10. Install the 5/16" bolt provided from the top.**
- 11. Install the nylock nut on the bolt a hole it and tighten for a snug fit.**
- 12. Repeat for the other side.**
- 13. Check function to make sure that the brake pedal works properly and that all of the clearances are good.**
- 14. That's it—you're done. Be sure and tell your other RS buddies. :-)**

Enjoy your new Floorboards and ryde in comfort. C-YA RL

spyderrt@yahoo.com

www.spyderrt.info