

## Installation instructions for Spyder RT splashguard footrests

### Right side

1. Remove Middle side panel from right side.
2. Place right footrest on top of splashguard and line up footrest at the notch out.
3. Eyeball the placement until it looks right to you, and mark the 2 holes on splashguard.
4. Drill 2 - 1/8" holes, place footrest on splashguard and install 2 flat head screws. Caution—do NOT over tighten, just tight enough to hold the footrest in place.
5. Look at photos and drill a 3/16" hole in plastic shields which should place a mark on the footrest.
6. Remove the footrest and drill a 1/8" hole where you just left a mark with the drill in step 5.
7. Place footrest on splashguard again, install the 2 flat head screws, and then install the pan head screw in the hole that you just drilled in step 6.
8. Place a drop of dish soap on the 3 side panel studs.
9. Wipe the rubber grommets with some water.
10. Line up the side panel and press in place.
11. Don't forget to set the hook at the top rear of the panel.

### Left side

1. Remove middle side panel from Left side.
2. Remove the 2 lower grommets from the oil tank cover grill, pull the grill back, and hold it out of the way.
3. Remove the bolt from the lower support bracket and flex the plastic tab of the bottom rear side panel up and out of the way, exposing the lower support bracket.
4. Drill 3/16" holes where shown on the photo.

5. Look at photos and trim cut the upper corner of bottom rear side panel, just enough to allow footrest to fit into that area using a utility knife or side cutters. The plastic is flexible enough to complete this without removing any other screws or panels.
6. Flex the plastic tab back and install the bolt that you removed in step 2.
7. Place Left footrest on top of splashguard and line up footrest at the notch out.
8. Eyeball the placement until it looks right to you, and mark the 2 holes on splashguard.
9. Drill 2 - 1/8" holes, place footrest on splashguard and install 2 flat head screws. Caution—do NOT over tighten, just tight enough to hold the footrest in place.
10. Run the 3/16" drill through the holes you drilled in step 4 to mark the footrest.
12. Remove the footrest and drill a 1/8" hole where you just made a mark with the drill in step 10.
13. Place footrest on splashguard again, install the 2 flat head screws, and then install the pan head screw in the hole that you just drilled in step 11.
14. Place a drop of dish soap on the side panel studs.
15. Wipe the rubber grommets with some water.
16. Line up the side cover and press in place.
17. Don't forget to set the hook at the top rear of the panel.



