



Print this out in actual size.

Use it as a template to cut from a piece of metal roof flashing that can be purchased at any hardware store.

Install your Heat Shield by carefully slipping in behind the body panels.

The full pattern can be used and there is an optional cut out area along the top for additional engine cooling.

the optional area removed will not affect the shielding of your foot while it is on the RT Splashguard Footrest.

*InspectorGadget*

*www.spyderrt.info*

*863-873-7002*