

Installation instructions for Spyder RT Windshield Mask

Raise the windshield to the full UP position.

Remove the 2 torx screws from the back of the windshield trim covers with the torx wrench provided in your tool kit.

Gently lift the top part of the trim cover out just far enough, and carefully slide it down 3/8" where it should come unhooked from the bottom slot. Set it aside for now along with the screws.

Clean the windshield where the mask will be installed with rubbing alcohol to remove any road dirt, bug guts, oil film, or cleaning residue. Wipe windshield off with a lint free cloth until dry.

Now take the windshield Mask and remove a 3/4" wide strip of the backing from the middle---top to bottom.

Position the mask over the windshield starting at the center making sure everything is lined up. Be sure to hold the mask down 1/16" to 1/8" at the bottom of the windshield, as you will be trimming this off with a razor knife later. This makes for a cleaner job.

The side cut outs of the mask should line up close enough to the windshield mounting bolts.

Reposition the mask as needed for a good line up and then press in the center to secure the mask adhesive to the windshield.

Now fold back one side of the mask so you can grab the backing and using a credit card work from the center out wiping out any air bubbles as you gently remove the backing outward.

Do the same for the other side being careful not to stretch the mask.

Now trim the bottom along the windshield and maybe the bottom trim slots using a sharp razor or hobby knife.

Replace the trim covers in reverse order that you removed them and replace the screws.

There you're done. Enjoy your new Windshield Mask. C-YA RL

spyderrt@yahoo.com

www.spyderrt.info