

## Installation instructions for Spyder RT Rear Fender Muddflap

Use the 2 bottom license plate holes as a guide and drill the 2 - ¼" holes into the plastic fender.

Use caution as to not drill to deep and puncture the tire.

Now place the SS screws through the concave washers and then into the holes you just drilled in the fender.

Next comes the rubber muddflap with any curvature following the rear tire.

Install the wire on the screws so when it is tightened up it will force the muddflap away from the tire.

Place the flat washers on, then the stop nuts, and tighten them up.

The bottom license plate hole provide a place to put your screwdriver for tightening.

There you're done. Enjoy your new Muddflap. C-YA RL

[spyderrt@yahoo.com](mailto:spyderrt@yahoo.com)

[www.spyderrt.info](http://www.spyderrt.info)