

Installation instructions for Spyder RT Cup Holder

Remove the stop nut holding the cup holder to the mounting bracket and remove the cup holder.

Remove both of the stop nuts holding the 1/8" x 3/4" bracket and remove the bracket

Place the U bolt assembly around the handlebar from the rear toward the front with the shorter part on the top.

Place the bracket on the U bolt and place the stop nuts on loosely.

Be sure that you position the assembly as far inward as possible and line up the bracket so is straight up before tightening the nuts.

Be sure to tighten the top nut first and only until the threads from the U bolt just start to extend past the nut.

Now tighten the bottom stop nut until the bracket is touching the rubber tube completely hiding the U bracket around the handlebar.

Now attach the cup holder as it was mounted to the bracket when you received it

Enjoy your drink holder and keep hydrated. C-YA RL

spyderrt@yahoo.com

www.spyderrt.info